

---

**CADWe'll Tfas ネットワークライセンス（WEB 版） HASP ドライバ障害対応方法**  
**（これから製品をインストールするお客様向け—Windows8.1 32bit 版）**

対応の手順

下記 3 つの手順を実行します。

手順 1 : Sentinel HASP ドライバーのダウンロードと適用

手順 2 : Sentinel HASP ドライバーの更新確認

手順 3 : CAD のインストール

以下、順を追って説明いたします。

## 手順 1 : Sentinel HASP ドライバーのダウンロードと適用

1-1. 下記 URL をブラウザで開きます。

<http://sentinelcustomer.safenet->

[inc.com/sentineldownloads/?s=&c=End+User&p=Sentinel+HASP&o=Windows&t=Runtime+%26+Device+Driver&l=all](http://inc.com/sentineldownloads/?s=&c=End+User&p=Sentinel+HASP&o=Windows&t=Runtime+%26+Device+Driver&l=all)

The screenshot shows the Gemalto Sentinel Customer Community website. The page title is "SEARCH DOWNLOADS" and it includes a navigation menu with options like HOME, LATEST EVENTS, RESOURCES, CUSTOMER DISCUSSION, DOCUMENTATION, ABOUT GEMALTO, and TECHNICAL SUPPORT. Below the navigation is a search filter section with dropdown menus for User Category (End User), Product (Sentinel HASP), Operating System (Windows), and Type (Runtime & Device Dri...). There are also fields for Language (All) and Keyword, along with Search and Reset buttons. Below the filters is a table of search results. The table has columns for DESCRIPTION, VERSION, PRODUCT, OPERATING SYSTEM, SIZE, and RELEASED. Two results are shown, and the first one, "Sentinel HASP LDK - Windows GUI Run-time Installer", is highlighted with a red box. The footer of the page includes "CONTACT US | BLOG © 2018 Gemalto. All rights reserved."

DESCRIPTION	VERSION	PRODUCT	OPERATING SYSTEM	SIZE	RELEASED
Sentinel HASP LDK - Windows GUI Run-time Installer	7.80	Sentinel HASP, HASP HL, HASP4, Hardlock, Sentinel LDK	Windows	19 MB	2018-04-12
Sentinel HASP LDK - Command Line Run-time Installer	7.80	Sentinel HASP, HASP HL, HASP4, Hardlock, Sentinel LDK	Windows	18.5 MB	2018-04-12


1-2. 上図赤枠内の「Sentinel HASP LDK - Windows GUI Run-time Installer」をクリックし、最新ドライバー (Ver.7.80) をダウンロードします。

※使用許諾 (SAFENET END USER LICENSE AGREEMENT) の同意 (I Accept) を求められます。“I Accept” ボタンはページの末尾にあります。

※ダウンロードページでは、ポップアップの許可が必要です。

- 
- 1-3. ダウンロードしたファイル（Sentinel\_LDK\_Run-time\_setup.zip）を解凍し、「HASPUUserSetup.exe」を実行します。

注）管理者権限を持たないユーザーの場合、“ユーザーアカウント制御”が表示されます。



※管理者アカウントのパスワードは、システム管理者にお尋ねください。

※以降は、インストーラーの手順に従ってください。

## 手順 2 : Sentinel HASP ドライバーの更新確認

2-1. 下記 URL をブラウザで開きます。

<http://localhost:1947/int/diag.html>

下図赤枠内の表記が、最新バージョン (Ver.7.80) であることを確認します。

**gemalto** Sentinel Admin Control Center

### Diagnostics for Sentinel License Manager on TEST-OS

License Manager Version	21.0 Build 77827										
Computer Name	TEST (PID:1876 on Win32) <span>Create ID File</span>										
Host Operating System	Windows 7 Ultimate Build 7601 Service Pack 1 x86 Family 6 Model 15 Stepping 11										
LM Protocols	IPv4, IPv6 (TCP and UDP at port 1947) 192.168. . fe80:: :7f.ffe%12, fe80:: :192.168. . %11										
Uptime	0 days 0 hours 3 minutes 3 seconds										
Template Sets	_int_										
Current Template	English 10.0 (28 June 2017 Build 1)										
Current Usage	0 logins, 0 sessions										
Login Requests	0 (0 peak simultaneous logins)										
Requests	0 local, 9 remote, 9 total										
Data Volume	21,377 received, 217,499 transmitted										
Errors	0 Key related, 0 in Transport										
Client Threads	6 (6 peak)										
Memory Used	1,611,916 (1,084 blocks)										
Run-time	<table border="1"><tr><td>Run-time Installer</td><td>7.80</td></tr><tr><td>Run-time Package</td><td>7.80</td></tr><tr><td>hardlock.sys</td><td>3.92</td></tr><tr><td>fridge_lib</td><td>1.8</td></tr><tr><td>aksfridge.sys</td><td>1.78</td></tr></table>	Run-time Installer	7.80	Run-time Package	7.80	hardlock.sys	3.92	fridge_lib	1.8	aksfridge.sys	1.78
Run-time Installer	7.80										
Run-time Package	7.80										
hardlock.sys	3.92										
fridge_lib	1.8										
aksfridge.sys	1.78										

Generate Report

---

### 手順 3 : CAD のインストール

3-1. CADWe'll Tfas ネットワークライセンス (WEB 版) のインストーラーを起動し、製品をインストールします。

※以降は、インストーラーの手順に従ってください。

以上